# **Environmental Protection Agency**

# **Electric Dynamometer Coefficient Estimation Procedure**

This procedure is written for the Environmental Protection Agency, National Vehicle and Fuel Emissions Laboratory (NVFEL) internal use. The use of specific brand names by NVFEL in this procedure are for reference only and are not an endorsement of those products. This document may be used for guidance by other laboratories.

#### **NVFEL Reference Number**

002A

#### **Implementation Approval**

Original Procedure Authorized by EPCN #181 on 02-27-95

#### Revision Description

(1) 10-18-95 The purpose of this change is to revise the procedure as described in EPCN #190. All steps affected by this change are identified with (1) in the margin.

# Table of Contents

1.	Purpose	3
2.	Test Procedure	3
3.	Acceptance Criteria	3

## **Attachments**

Attachment A, Initial Input Screen	6
Attachment B, Form WP 002-01	7
Attachment C, Electric Dynamometer Coefficient Data Input Screen	9
Attachment D, Electric Dynamometer Coefficient Estimation Report	. 10

#### 1. Purpose

(1) The purpose of this procedure is to document the steps required to provide estimated A, B, and C coefficients for setting the Horiba 48-inch electric dynamometer road load. These coefficients do not simulate vehicle air-conditioning (A/C) loading.

Form WP 002-01 is to be used with this procedure.

#### 2. Test Procedure

Go to room 516 and, if not already on, turn on the Macintosh computer that has the database named "Elec Dyno Coefficients" stored on it. Double-click on this file and enter the password.

The program will open to a start-up screen. Click on the "Enter the initial coastdown data" button.

This will switch to "Initial Input" screen (Attachment A) that will allow you to enter today's date and the data related to the vehicle.

- **Note:** If you click on the "Find last report and print it" button the program will automatically find the last data entered and print the corresponding report and return to the start-up screen.
- 102 Click on the "New Record" button to get a blank input screen and enter the initial vehicle data. Do not write over or change any existing data.
- 103 Click on the "Print Forms" button. This will automatically print Form WP 002-01 (Attachment B), which will have the initial vehicle data you entered recorded on the form.

The program will automatically switch to the "Electric Dynamometer Coefficient Data Input" screen (Attachment C), which is where you will later enter the data obtained in Steps 105 through 107.

- Locate the vehicle. Any time the vehicle needs to be moved, it may be driven. If any problems are encountered with the vehicle, contact the EF Project Officer.
- Record the required data and follow the instructions in Steps 1.0 through 10.0, as described on Form WP 002-01.

Step 11.0 of Form WP 002-01 requires you to transcribe the data to the Horiba Electric Dyno database. Locate the Horiba Dyno Computer and open the "Vehicle Classes" database.

Transcribe the data as follows:

Vehicle ID. = Vehicle Class Name

Equivalent Test Weight = Dyno Set Inertia

Total Weight = Vehicle Weight

Drive Axle Weight = Driving Wheel Weight

Enter 0 (zero) for the Dynamometer Set and Target A, B, and C coefficients

- (1) **Note:** The computer program corrects the coefficients to produce dynamometer coefficients without an additional vehicle air conditioning load. This is accomplished by inputting the A/C adjusted coast down time and multipling the resulting C-set coefficient by 0.9.
  - 107 Continue following the instructions and recording data as required on Form WP 002-01 until the coastdowns have been completed, the remaining data is transcribed to the Horiba computer, and the "Electric Dynamometer Coefficient Estimation Report" (Attachment D) is printed.
  - Distribute the reports as described on WP 002-01.

#### 3. Acceptance Criteria

The following criteria must be met for the coastdown to be valid:

- 3.1 Only one drive-axle may be indicated on the "Electric Dynamometer Coefficient Estimation Report."
- 3.2 The vehicle fuel tank must be drained and then filled to 40% of the tank volume.
- 3.3 The vehicle total weight must be equal to the sum of the drive-axle and the non-drive-axle weight.
- 3.4 The vehicle must soak at 68-86 °F for a minimum of 4 hours, immediately before the coastdown.
- 3.5 The drive-axle tire pressure must be within  $\pm 1.0$  psi of the manufacturer's recommended tire pressure before the coastdown.

- 3.6 The non-drive-axle tire pressure must be within  $\pm 1.0$  psi of the manufacturer's recommended tire pressure before the coastdown.
- 3.7 The coastdown measurements must begin within 1 minute of the end of the drive-axle and non-drive-axle warm-ups.
- 3.8 The "Dynamometer Set Road Load Coefficients" must meet the following:

$$-2.5 < B < 2.5 \text{ lb/mph}$$

$$0 < C < 0.09 \text{ lb/(mph)}^2$$

- (1) 3.9 The A, B, and C "Target Road Load" coefficients should be entered as zero in the Horiba Dyno Computer database menu.
- (1) 3.10 The technician who performed the procedure records his/her assigned Environmental Protection Agency ID# on Form WP 002-01.

002A

**Electric Dynamometer Coefficient Estimation Procedure** 

Page 6 of 10

WP 002A

**Attachment A** 

Page 6 of 10

# **Initial Input**

Click on the "New Record" button before entering the data

New Record

Enter the Today's Date, Vehicle ID., Manufacturer, Model, Model year, and Drive Axle information

Today's Date	_		
Vehicle ID			
Manufacturer		_	
Model			
Model Year			
Drive Axle. Front ☐ Rear			

Print Forms

## **Attachment B**

	Electric Dynamometer Coefficient Estimation Data
1.0	Record the Today's Date, Vehicle ID., Manufacturer, Model, Model year, and Drive Axle information.
	Today's Date
	Vehicle ID
	Manufacturer
	Model
	Model Year
	Drive Axle, Front ☐ Rear ☐
2.0	Drain the vehicle fuel tank and fill it to 40% of the volume. Record the total volume and 40 % gallons.
	Fuel Tank Volume gallons
	40% Fuel Tank Volume gallons
3.0	With the driver in the vehicle, weigh the drive axle, non-drive axle, and the total vehicle. Record these weights.
	Drive Axle Weight with Driver pounds
	Non-Drive Axle Weight with Driver pounds
	Total Weight pounds
4.0	Record the Equivalent Test Weight
	Equivalent Test Weight pounds
5.0	Record the Tire Manufacturer Make and Size. Record the Vehicle Manufacturer's Recommended Pressure.
	Make, Front Size, Front Recommended psi, Front Tire
	Make, Rear Size, Rear Recommended psi, Rear Tire
6.0	Set the tire pressure to 5 psi above the manufacturers recommended pressure. Record these pressure settings.
	Drive tire pressure set to: psi
	Non-drive tire pressure set to: psi
7.0	Park the vehicle in the soak area for a minimum of 4 hours. Record the soak start date and time.
	Soak Start Date Soak Start Time
8.0	Record the soak end date and time
	Soak End Date Soak End Time
9.0	Record the Clayton AHp.
	Clayton 50 mph AHp hp
10.0	Record the A/C adjusted 55-45 mph coastdown time.
	Coastdown Time seconds
11.0	, I
	Vehicle ID. = Vehicle Class Name, Equivalent Test Weight = Dyno Set Inertia, Total Weight = Vehicle Weight, and the Drive Axle Weight = Driving Wheel Weight.
	Enter 0 (zero) for the Dynamometer Set and Target A, B, and C coefficients.
12.0	If necessary, warm-up the dynamometer, update the Auto Calibration Offset, the Span values, and the Parasitic Loss Calibration Curve.
13.0	Drive the vehicle into the test cell and place the drive axle tires on the dynamometer.
	<b>13.1</b> Restrain the non-drive wheels using the wheel chock system. Use the cross tie cables for front wheel drive vehicles.
	Page 1 of 2 Form WP 002-01: 10-18-95

## Attachment B continued

		Electric Dynamometer Coefficient Estimation Data			
	Toda	y's Date			
	Vehic	ele ID			
	13.2	Position the front cooling fan.			
	13.3	Reduce the drive axle tire pressure to the vehicle manufacturer's recommended tire pressure $\pm\ 1.0$ psi.			
		Final drive axle tire pressure set to: psi			
14.0	vehic	n-up the drive axle tires for 25 minutes by motoring the dynamometer at 50 mph. The driver must be in the le, with the dynamometer emergency stop button within reach, the engine on, A/C off, and the mission in neutral.			
15.0	Withi	in 1 minute of the end of the warm-up, run one 70-10 mph coastdown with 5 mph speed intervals.			
16.0		the coastdown is complete, exit the vehicle and use the Horiba computer Alt - P command twice to print s of the tabular summary report.			
17.0	Label	the reports "Drive Axle."			
18.0	Enter	the measured coastdown coefficients for the drive axle into the data base.			
19.0	Place	the non-drive axle tires on the dynamometer.			
	19.1	Restrain the drive wheels using the wheel chock system. Use the cross tie cables as necessary.			
	19.2	Position the front cooling fan.			
	19.3	Reduce the non-drive axle tire pressure to the vehicle manufacturer's recommended tire pressure $\pm$ 1.0 p			
		Final non-drive axle tire pressure set to: psi			
20.0	Warn in the	n-up the non-drive axle tires for 25 minutes by motoring the dynamometer at 50 mph. The driver must be vehicle, with the dynamometer emergency stop button within reach, and the transmission in neutral.			
21.0	Withi	n 1 minute of the end of the warm-up, run one 70-10 mph coastdown with 5 mph speed intervals.			
22.0	When the coastdown is complete, exit the vehicle and use the Horiba computer Alt - P command twice to print copies of the tabular summary report.				
23.0	Label the reports "Non-drive Axle."				
24.0	Return to the Macintosh and transcribe all the required data from this form and the 2 tabular summary reports the drive axle and non-drive axle measured coastdown coefficients into the Electric Dynamometer Coefficient Estimation data base.				
	Push	the Print Reports button. This will automatically print 2 copies of the report.			
25.0					
26.0	Give Repo	Form WP 002-01, the 2 Horiba tabular reports and one copy of the Electric Dynamometer Coefficients rt to the EF Project Officer. Give the remaining reports to EOD Large-roll Dyno Project Officer.			
	I have	e performed all steps in accordance with the requirements of WP 002.			
	Techi	nician's Name: Date:			
	The d	lata entries are accurate and meet the requirements of WP 002.			
	Verif	ied by: Date:			
		Page 2 of 2 Form WP 002-01: 10-18-95			

# Attachment C Electric Dynamometer Coefficient Data Input

Follow the directions on Form WP 002-01 and perform the coastdowns. When completed, return to this computer and enter the remaining required data.

When all of the data has been entered, pus Vehicle ID	_
Vehicle ID	Today's Date
Model	
Model Year	
Drive Axle, Front ☐ Rear ☐	
Fuel Tank Volume	gallons
40% Fuel Tank Volume	gallons
Dive Axle Weight with Driver	pounds
Non-Drive Axle Weight with Driver	
Total Weight	
Equivalent Test Weight	
Tire Make, Front	
Tire Size, Front	
Recommended psi, Front Tire	
Tire Make, Rear	
Tire Size, Rear	
Recommended psi, Rear Tire	
Drive tire pressure set to:	psi
Non-drive tire pressure set to:	
Soak Start Date	
Soak Start Time	
Soak End Date	
Soak End Time	
Clayton 50 mph AHp	
A/C Adjusted Coastdown Time	
Final drive tire pressure set to:	
Final non-drive tire pressure set to:	
Drive Axle A	
Drive Axle B	
Drive Axle C	
NonDrive Axle A	
NonDrive Axle B	
NonDrive Axle C	
Technician Name	
Form Verified By:	Date:

## **Electric Dynamometer Coefficient Estimation Procedure**

## **Attachment D**

	•			Estimation Report
Vehicle ID:				
Manufacturer: Technician Name:				
	Drive Axle, Front□	-		
L	Rear □			
Fu	el Tank Volume:	الدم	one	
	el Tank Volume:			
	eight with Driver:			
	eight with Driver:			
TONDITY TIME W	Total Weight:			
Equiva	lent Test Weight:			
=				
	Tire Size, Front:			
	ended psi, Front:			
	re pressure set to:			P3-
	re pressure set to:			
	re pressure set to:			
	re pressure set to:			
	Soak Start Date:			
	Soak Start Time:			
	Soak End Date:			
	Soak End Time:			
Clayt	on 50 mph AHp:	hp		
A/C Adjusted (	Coastdown Time:	sec	onds	
Drive Axle A:	NonDrive Axl	le A:		Dyno Set Road Load A:
Drive Axle B:	NonDrive Axl	le B:		Dyno Set Road Load B:
Drive Axle C:	NonDrive Axl	le C:		Dyno Set Road Load C:
Quality Checks:				
	/ Checks" flags, docume			own, in the comments section.
	.00.1	. 1		
I verify that Form WP 0		•		
Verified By :		Date:		